

Parts list for:

## Concealed SKYscreen (CSS2)

- 1 Cover extrusion
- 2 Roller extrusion
- 3 Roller bearing
- 4 Spring A (all screens)
- 5 Blackout Cloth
- 6 Double sided tape
- 7 Monofilament
- 8 End plate LH
- 9 End plate RH
- 10 X-bar
- 11 Pusher LH
- 12 Pusher RH
- 13 Magnetic extrusion
- 14 Hook
- 15 Clinch nut
- 16 Button plate
- 17 X-bar end cap LH
- 18 X-bar end cap RH
- 19 Side rail
- 20 Hook spring
- 21 Button
- 22 Screw caps (4 off)
- 23 Flyscreen
- 24 Pusher spring
- 25 Brush strip
- 26 M4 x 12.0 mm screws (4 off)
- 27 M3 x 4.5 mm screws (8 off)
- 28 N3.5 x 19.0 mm self tapping screw (16 off)
- 29 Spring bush
- 30 Plate bearing

NOTE: ALL PARTS 2 OFF UNLESS OTHERWISE STATED

