




DOMETIC ROMANBLIND

Profile
Manual - Guide wire - Without cord lock



- Notes:
- 1 The position of the lift cord can be varied if necessary.
 - 2 Refer to Oceanair for further stack height information.
 - 3 Refer to product guide for Min/Max dimensions.
 - 4 Cleat required to hold blind in position.
 - 5 Bracket quantity dependant on width of blind.