


VIEW FROM INBOARD



X(Width) & Y(Drop) Limits			
X (Min)	X (Max)	Y (Min)	Y (Max)
430 [16 15/16"]	3000 [118 1/8"]	400 [15 3/4"]	3000 [118 1/8"]

- Notes:
- 1 Motor exit wire can exit either side, please specify.
 - 2 Allow sufficient space for installation.
 - 3 Dimensions in millimeters (Imperial equivalents are shown for references only).
 - 4 Oceanair reserves the right to modify or change dimensions and specifications without prior notice.