SKYVIEW - Powered - Somfy LT28 - Guide wire







VIEW FROM INBOARD



Fixing brackets top fix



Guide fixing options

X(Width) & Y(Drop) Limits			
X (Min)	X (Max)	Y (Min)	Y (Max)
400 [15 3/4"]	3000 [118 1/8"]	400 [15 3/4"]	3000 [118 1/8"]

Notes:
1 Motor exit wire can exit either side, please specify.
2 Allow sufficient space for installation.
3 Dimensions in millimeters (Imperial equivalents are shown for references only).
4 Oceanair reserves the right to modify or change dimensions and specifications without prior notice.

COPYRIGHT 2012 Dometic UK Blind Systems Ltd Atlantic House 1 Ellis Square Selsey West Sussex PO20 0AY UK - T: +44 (0) 1243 606909